

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

List of contents

Lot number	Item	4800 wells
_____	Antibody-coated 96-well microtiter plates	50 solid
_____	Peroxidase enzyme conjugate, concentrated	1 x 5.5 mL
_____	RUB6, enzyme conjugate diluent	1 x 550 mL
_____	TMB substrate	550 mL
_____	Positive control	5
	The above items should be stored at 2 - 8 °C	
_____	PBST wash buffer, powder or liquid	3 X 110 g
	The above items should be stored at room temperature (18 - 30 °C).	

Materials required, but not provided

Some of the items in the list below may be necessary depending on the type of samples and the method necessary to process the samples. Please refer to sample preparation section for guidance.

- Distilled or purified water
- Paper towels
- Micropipette
- Micropipette tips
- Airtight container for incubations
- Negative control (Agdia catalog number: LNC 06700 - *Please specify leaf or seed control when ordering.*)
- Scissors, marker, timer
- Single seed and leaf extraction equipment.
 - Seed press or seed crusher and plate
 - Agdia sample mesh bag (ACC 00930) and rubber mallet or marker with bag stand
 - Mortar and pestle
 - Micro tube and pestle with tube rack
- Graduated cylinder
- Analytical balance
- Microtubes and tube rack

Storing the reagents

Store all kit components at the recommended temperature to assure their full shelf life. Each ELISA plate pouch contains a desiccant packet. Keep the plate or unused testwells sealed in the pouch with the desiccant and store in the refrigerator (2 - 8 °C) between uses. Allow the components of the kit to warm to room temperature for about 30 minutes before using.

Technical service

If you have any questions about using this kit, please contact Agdia, Inc. Monday – Friday by phone (574-264-2014 or 800-622-4342) or by email (info@agdia.com).

Precautions

Prevent direct skin and eye contact with, or ingestion of, kit components. Obtain medical attention in case of accidental ingestion of kit components. It is recommended that gloves be worn while performing the assay. Always wash hands thoroughly after using the kit.

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

Intended Use

This ELISA was developed for the qualitative detection of the mBt-Cry3A protein when testing individual corn seed and leaf. The mBt-Cry3A protein is expressed in Syngenta corn rootworm event, MIR604, trade name Agrisure® RW.

The mBt-Cry3A antibody recognizes mBt-Cry3A protein and shows no cross-reaction with Bt-Cry3Bb1, Bt-Cry34Ab, Bt-Cry1Ab, Bt-Cry1Ac, Bt-Cry1F, Bt-Cry9C, CP4 EPSPS (Roundup Ready®), or PAT (Liberty Link®).

*LibertyLink® is a registered trademark of Bayer CropScience.
Roundup Ready® is a registered trademark of Monsanto Company.
Agrisure® RW is a registered trademark of Syngenta Group Company*

Test Principle

The test system for mBt-Cry3A is a direct DAS ELISA. Monoclonal antibodies specific to mBt-Cry3A are coated to the testwells of a microplate. An enzyme conjugate solution has been included in this kit containing monoclonal antibodies specific to mBt-Cry3A conjugated to a peroxidase enzyme. Enzyme conjugate is added to the testwells followed by sample extracts. If mBt-Cry3A is present in the sample, it is bound by the antibodies and captured on the microplate. The plate is then washed to remove any unbound enzyme conjugate and sample. Finally, a substrate is added to the microplate. If peroxidase is present, a color will be produced signifying the presence of mBt-Cry3A. The color reaction can be measured with a plate reader or observed visually.

Please read these instructions carefully before performing the test.

Limitations

The following is a description of factors that could limit test performance or interfere with proper test results.

Buffers: Prepare only the amount of 1X buffers needed for the day. Dilute only the amount of enzyme conjugate necessary at the time of each test run. Do not store 1X buffers.

Samples: This test has been evaluated in corn only.

Sample Extraction Buffer: The mBt-Cry3A ELISA must be used with PBST wash buffer for optimal results. Do not use sample extraction buffers used with other ELISA kits.

Sample Dilution: ELISA performance is very dependent on the proper sample dilution (tissue weight in g: buffer volume in mL).

Expiration: Test should be used within one year of purchase.

Storage: Test results may be weak or the test may fail if the storage instructions are not followed properly.

Timing: Please follow times provided for extraction and incubation. Timings for each sample type have been optimized to give the best results for both negative and positive samples. **Not adhering to these exact times will interfere with achieving proper test results.**

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

Preparing for the test

Familiarize yourself with the kit components and check that all components are present in the kit.

Prepare buffers

PBST wash buffer has been provided in either liquid or powder form. Depending upon your kit size, prepare according to directions as follows:

Prepare 1X PBST wash buffer by diluting one 20X pouch of PBST wash buffer with 950 mL of distilled water.

Prepare 1X buffer by dissolving PBST buffer powder in distilled water according to the table below:

Buffer	5 g
Distilled water	500 mL

Prepare controls

Reconstitute lyophilized positive control and lyophilized negative control with 2.0 mL of prepared PBST sample extraction buffer per bottle.

Make control aliquots

After preparing the positive and negative control, divide them into aliquots, each sufficient for one use. Dispense aliquots into tubes that can be securely capped. If you will be using a control in one well each time you run the test, prepare 120 μ L aliquots. If you will be using a control in two wells, prepare 220 μ L aliquots. Each aliquot should be sufficient for the tests to be run plus a small additional volume to assure easy dispensing.

Control aliquots must be stored frozen (-10 to -30 °C freezer or household freezer). Do not thaw until just before use. At the time of each test run, remove from storage only the aliquots that will be used. Allow the tubes to thaw and mix the contents thoroughly. At the time you add sample extracts to testwells, add the same volume of negative and positive control to the appropriate control wells.

Do not refreeze controls.

Prepare humid box

Prepare a humid box by lining an airtight container with a wet paper towel. Keeping testwells in a humid box during incubation will help prevent samples from evaporating.

Make a copy of the loading diagram and record the locations of your samples and controls. We recommend that you use a buffer well, negative control well and positive control well on each plate each time you run the test.

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

Preparing Single Leaf and Seed Samples

Leaves, seedlings, or seeds must be ground and diluted in PBST sample extraction buffer. For best results, samples should be diluted in PBST buffer according to the ratios and times listed in the table below.

Individual leaves

Sample grinding in Agdia sample mesh bags.



For leaf samples use Agdia's sample mesh bags, a clean mortar and pestle, or any other grinding device that can break up leaf tissues and prevent contamination between samples.

A simple method for grinding a single leaf sample is by using Agdia's sample mesh bags. Use only one sample per bag and be sure to label each bag. Place the leaf sample between the mesh linings of the bag. Rub the bag with a marker to completely crush the sample and to mix the contents uniformly. Add the appropriate volume of PBST buffer to the bag containing the crushed leaf following a 1:20 (tissue weight in g: buffer volume in mL) leaf to buffer ratio and massage the bag by hand for a few seconds to ensure good extraction. Let the extract sit for 3-5 minutes. Transfer diluted sample to the testwells of the ELISA plate.

Single seeds

Single seeds can be crushed in a seed press, seed crusher or sample mesh bag and rubber mallet. Wash and rinse the grinding equipment between samples.

Determine the weight of the seed. Crush and add the appropriate volume of PBST buffer following a 1:2 (tissue weight in g: buffer volume in mL) seed to buffer ratio. Mix, on a rotary shaker, for 15 minutes to ensure good extraction. Transfer diluted sample to the testwells of the ELISA plate.

Tissue	Tissue to buffer ratio	Examples
Leaf	1:20 g:mL	Example: Initial leaf weight of 0.1 g <ul style="list-style-type: none">• Add 2 mL of PBST to crushed leaf in mesh bag.• Allow to extract for 3-5 minutes.
Seed	1:2 g:mL	Example: Initial seed weight of 0.30 g <ul style="list-style-type: none">• Add 0.6 mL of PBST to crushed seed.• Allow to extract for 15 minutes.

Test Procedure

1. Prepare enzyme conjugate

Note: Always prepare enzyme conjugate within 10 minutes before use.

The enzyme conjugate is supplied as a concentrate and must be diluted with RUB6 diluent before use. The total amount of RUB6 diluent required depends on the number of testwells used. You will need 100 μ L of buffer for each testwell you are using, plus an additional amount to assure easy dispensing. Dilute only the amount of enzyme conjugate needed for your test run.

Example: If the dilution given on the bottle of concentrated enzyme conjugate is 1:100, and you are preparing 10 mL of enzyme conjugate solution, you should first dispense 10 mL RUB6 diluent. Then, add 100 μ L of the concentrated enzyme conjugate to the RUB6 diluent.

After adding the enzyme conjugate, mix thoroughly. It is important to mix the enzyme conjugate solution well.

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

2. Add enzyme conjugate Dispense 100 μ L of enzyme conjugate per well.

3. Dispense samples, controls, and buffer Following your loading diagram, dispense 100 μ L of each prepared sample into sample wells. Dispense 100 μ L of positive control into the positive control wells, 100 μ L of negative control into the negative control wells, and 100 μ L of PBST buffer into the buffer wells.

Mix the contents of the wells by gently swirling the plate on the bench-top.

4. Incubate plate Set the plate inside the humid box and incubate at room temperature. Use the table to determine appropriate time for sample type.

Single Leaf Sample	Single Seed Sample
1 hour	2 hours

5. Warm TMB substrate About 15 minutes before the end of the above incubation step, measure the required amount of TMB substrate needed. Return the remaining TMB substrate to the refrigerator. Allow measured TMB substrate to warm to room temperature. Caution: The TMB substrate is light sensitive, extra precautions are necessary to protect it from light sources when warming to room temperature.

You will need 100 μ L of substrate for each testwell you are using. A full plate will require about 10 mL.

6. Wash plate When the sample incubation is complete, wash the plate. Use a quick flipping motion to dump the wells into a sink or waste container without mixing the contents.

Fill all the wells completely with 1X PBST, and then quickly empty them again. Repeat 7 times.

After washing, hold the frame upside down and tap firmly on a folded paper towel to remove all droplets of wash buffer.

Note: If using an automatic plate washer, please be sure that the machine is at the appropriate settings for washing flat bottom plates.

7. Add TMB substrate Add 100 μ L of the TMB substrate solution into each well of the plate. Let the plate incubate according to the table below. Keep testwells away from strong light.

Leaf Sample	Seed Sample
30 minutes	30 minutes

mBt-Cry3A ELISA Kit

Qualitative DAS ELISA for the detection of the mBt-Cry3A transgenic protein
Catalog number: PSP 06700

8. Evaluate results

Measure O.D.'s on a plate reader at 650 nm. Air bubbles which are present at the time of reading can alter results, if in the light path. Agdia recommends that bubbles be eliminated prior to reading.

Wells in which a blue color develops indicate positive results. Wells in which there is no significant color development indicate negative results. Test results are valid only if positive control wells give a positive result and buffer wells remain colorless.

If either control well does not show the appropriate color, please repeat the test procedure. If the problem persists, contact Agdia for further assistance.

Buffer Formulations

The following buffer is a standard part of your kit. This formulation is for reference only.

PBST Buffer (Wash Buffer) (1X)

Dissolve in distilled water to 1000 mL:

Sodium chloride	8.0 g
Sodium phosphate, dibasic (anhydrous)	1.15 g
Potassium phosphate, monobasic (anhydrous)	0.2 g
Potassium chloride	0.2 g
Tween-20	0.5 g

Adjust pH to 7.4

Date _____ Test _____

Test performed by _____

	1	2	3	4	5	6	7	8	9	10	11	12
A												
B												
C												
D												
E												
F												
G												
H												