

# T1B1840

18GA BRAD NAILER



Air Pressure: 80-110 PSI

Max Air Pressure: 120 PSI

Air Fitting Size: 1/4" NPT

## Loading

- Load the fastener strips by resting on the bottom of the magazine, and push the strips toward the nose area.  
**Magazine Capacity:** 100 fasteners.
- Pull the magazine pusher back and rest on the back of the brads.



## Actuation Modes


Selectable Actuation Trigger

Sequential Trigger (Restrictive) available (AS-21040)

Turn the red button to switch the firing mode.

1. Full Sequential Actuation  
(Factory Preset)

2. Contact Actuation  
(Bump Fire)



## Depth Adjustment

- Turn the wheel clockwise to reduce the penetration (as shown).
- Turn the wheel counterclockwise for deeper penetration (as shown).
- Reducing or increasing the air pressure can also affect the depth of the drive.

