

# TROUBLESHOOTING TIPS

## LEN GORDON TF-1 & TF-1 DUAL CONTROLS



PROBLEM	PROBABLE CAUSE	CORRECTIVE ACTION
Garbage Disposal Does Not Turn "On"	Defective "On" & "Off" Air Button	Disconnect the air line (tubing) from the on/off switch box. Using your finger, plug the end of the tubing. Press the air button. If you feel no resistance, check the air button and replace if necessary. If there is resistance, check the air switch box.
	Damage or Disconnected Air Line (Tubing)	Check to make sure the air line is connected to the air switch box and the air button. Inspect the air line (tubing) for any damages, kinks and punctures. Replace if necessary. Check the air switch box.
	Defective Air Switch Box	Disconnect garbage disposal unit from the air switch box. Plug in a night light (or equivalent) to the air switch box. Press the air button. If light does not go on, replace the air switch box. If the night light turns on & off, the air switch box is good. Check the garbage disposal unit.

**All controls must be installed by a licensed spa technician or electrician. If you need further assistance, please contact our Technical Service Department at 800-237-9937.**



*Manufacturing the Product Lines of Len Gordon*

7215 Bermuda Road Las Vegas, NV 89119-4304  
 Phone: 800-237-9937 Fax: 866-909-7278  
 E-mail: [technical@alliedinnovations.com](mailto:technical@alliedinnovations.com)  
 Website: [www.alliedinnovations.com](http://www.alliedinnovations.com)