



Knife Leash Kit Instructions

The Cook's Brand Knife Leash Kit helps to address issues with lost, misplaced, or stolen knives by securely locking items to a worktable. This kit can also be used to secure dishers, peelers, and other kitchen tools.

Follow these steps to install the Knife Leash Kit:

1. Drill hole in knife handle. Approximate hole size should be 1/8" to 3/16".
2. Thread security fastener through hole in knife (Figure 1). Screw the set screw into the end of the fastener. Be careful not to break the tightening bar off.




Figure 1. Thread the Security Fastener

3. Feed the end of security wire into the opposite end of the security fastener and tighten until the set screw breaks off (Figure 2).




Figure 2. Tighten the Set Screw

4. Thread the knife leash cable through the security fastener loop and through loop in the opposite end of the cable (Figure 3).




Figure 3. Thread the Knife Leash Cable

5. Secure to table with provided lock (Figure 4).




Figure 4. Secure to Table