
MODEL CB1819C



1100 Hicks Road, Rolling Meadows, IL 60008 P: 800-873-2239 / 847-259-1620 ◆ F: 888-369-2588 customerservice@spotnails.com www.spotnails.biz ◆ www.spotnails.com



| | Ref No. | Part No. | Description | | Ref No. | Part No. | Description | | |
|------------|---|----------|----------------------|---|---------|----------|-----------------------------------|--|--|
| | 01 | P-70043 | Exhaust Deflector | • | 38 | P-64421 | O-Ring | | |
| | 02 | P-64392 | O-Ring | | 39 | P-22170 | Lower Valve Housing | | |
| | 03 | P-60236 | Body Cap (Gray) | • | 40 | P-64241 | O-Ring | | |
| | 04 | P-24720 | Screw - 4PCS | | 41 | P-18337 | Spring | | |
| • | 05 | P-15199 | Exhaust Seal | | 42 | AS-21006 | Contact Trigger (Black)(Bump Fire | | |
| • | 06 | P-64332 | O-Ring | | 43 | P-07234 | Trigger Pin | | |
| | 07 | P-22167 | Poppet Valve Guide | | 44 | P-26126 | Nut | | |
| • | 80 | P-64393 | O-Ring | | 45 | P-64425 | Cap O-Ring | | |
| • | 09 | P-62072 | Gasket | | 46 | P-60237 | End Cap (Gray) | | |
| | 10 | P-18226 | Spring | | 47 | P-13040 | Bracket | | |
| • | 11 | P-64232 | Poppet O-Ring | | 48 | P-32171 | Washer - 2PCS | | |
| | 12 | P-63039 | Poppet Valve | | 49 | P-32144 | Spring Washer - 3PCS | | |
| • | 13 | P-64233 | Piston Stop O-Ring | | 50 | P-24304 | Screw - 2PCS | | |
| • | 14 | P-64234 | Cylinder Seal O-Ring | | 51 | P-32170 | Washer | | |
| | 15 | P-03071 | Guide Spacer | | 52 | P-24450 | Screw | | |
| • | 16 | P-64394 | O-Ring | | 53 | P-12229 | Magazine | | |
| | 17 | P-03072 | Cylinder Spacer | | 54 | P-24317 | Screw | | |
| • | 18 | P-64616 | Cylinder O-Ring | | 55 | P-18231 | Latch Spring | | |
| | 19 | P-05099 | Cylinder | | 56 | P-09148 | Pusher | | |
| • | | P-64395 | Cylinder O-Ring | | 57 | P-18229 | Spring Stem | | |
| • | 21 | P-64236 | Piston O-Ring | | 58 | P-18230 | Feeder Spring | | |
| | 22 | P-15121 | Bumper | | 59 | P-07237 | Pusher Stop Pin | | |
| • | 23 | P-15122 | Return Seal | | 60 | P-12230 | Magazine Cover | | |
| | 24 | P-01264 | Body | | 61 | P-04049 | Latch | | |
| | 25 | P-32143 | E-Ring - 2PCS | | 63 | P-24364 | Screw | | |
| | | P-18228 | Contact Arm Spring | | 64 | AS-06139 | Piston & Driver Assembly | | |
| | 27 | P-07336 | Contact Pin | | 65 | P-06312 | Driver Blade | | |
| | 28 | P-53168 | Safety | | 66 | P-07356 | Step Pin | | |
| | | P-24300 | Screw - 2PCS | | 67 | P-07353 | Pin | | |
| | 30 | AS-10058 | Front Plate Assembly | | 68 | AS-04045 | Latch Assembly | | |
| | 31 | P-08468 | Wear Plate | | 69 | | Sequential Trigger (Red) | | |
| • | | P-64239 | Valve Housing O-Ring | | 70 | P-64434 | O-Ring | | |
| | | P-22168 | Upper Valve Housing | | 71 | P-24483 | Screw | | |
| \dashv | | P-18336 | Spring | | 72 | P-27189 | Wear Insert | | |
| • | | P-64240 | Valve Stem O-Ring | | 78 | P-15271 | Return Seal | | |
| | 37 | P-22169 | Plunger | | 79 | P-32229 | Spring Washer | | |
| → ˈ | ◆ Parts Included In AS- 97283 O-Ring And Seal Kit | | | | | | | | |

ACCESSORIES (NOT INCLUDED)

| | 73 | P-96198 | No Mar Tip | 76 | P-53202 | Safety For No Mar Tip |
|---|----|---------|------------|----|----------|------------------------|
| Г | 74 | P-32290 | Washer | 77 | AS-53078 | No Mar Safety Assembly |
| Г | 75 | P-26189 | Nut | | | |