

# SP2340

18GA Brad Nailer



Air Pressure: 80-110 PSI

Max Air Pressure: 120 PSI

Air Fitting Size: 1/4" NPT

## Loading


- Push the magazine latch and pull back cover .
- Load the fastener strips by resting on the bottom of the magazine, and make sure that the arrows on fasteners are facing down.

**Magazine Capacity:** 100 fasteners.

- Push the magazine cover forward until locked.



Arrow Symbols Facing Down



## Actuation Modes

- Contact Actuation (Bump Fire).

## Depth Adjustment

- This tool does not have a depth adjustment.
- Reducing or increasing the air pressure will affect the depth of the drive.