

Pump Bracket Instructions



Pump Bracket
PT# 6000-53X-HQ



For Bracketless Pumps



Pump with Bracket Installed

Tools Required:


1/2" Wrench or Socket

Replaces: 6000-532, SD6000-532, 35-455-1010, 6000-535, SD6000-535, 35-455-1012

INSTRUCTIONS:

Step 1:

Insert both Band Clamps in Bracket slot according to pump size (56F or 48F).



Step 2:

Place the pump on the Bracket



Step 3:

Wrap Band Clamps around the pump motor body and Insert bolt through both Band Clamps and tighten to secure the pump motor

