


MODEL SP2340



SPOTNAILS®

Division of Peace Industries, LTD.

1100 Hicks Road, Rolling Meadows, IL 60008
P: 800-873-2239 / 847-259-1620 • F: 888-369-2588
customerservice@spotnails.com
www.spotnails.biz • www.spotnails.com

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24385	Cap Screw - 4PCS	34	AS-21006	Trigger Assembly(Black)
02	P-70050	Exhaust Cover	35	P-07372	Trigger Pin
◆ 03	P-15181	Exhaust Seal	36	AS-53097	Safety Assembly
04	P-60191	Cap	37	P-24364	Cap Screw - 2PCS
◆ 05	P-64463	O-Ring	38	P-10303	Front Plate
◆ 06	P-64372	O-Ring	39	P-24452	Cap Screw - 2PCS
07	P-18326	Spring	40	P-24311	Cap Screw - 2PCS
◆ 08	P-64366	O-Ring	41	P-08491	Wear Plate
09	P-63036	Poppet Valve	42	P-24478	Cap Screw - 4PCS
◆ 10	P-64367	Cylinder Seal O-Ring	43	P-27186	Wear Rail
◆ 11	P-64368	Piston Stop O-Ring	44	P-27187	Wear Insert
12	AS-63021	Poppet Assembly	45	P-12470	Magazine
13	P-05111	Cylinder	46	P-24479	Screw - 2PCS
◆ 14	P-64464	Cylinder O-Ring	47	P-96135	Tension Plate
◆ 15	P-64465	Piston O-Ring	48	P-13091	Bracket
16	AS-06070	Piston & Driver Assembly	49	P-04077	Latch
17	P-52040	Safety Guide	50	P-24477	Cap Screw - 5PCS
18	P-32144	Washer	51	P-04078	Rear Latch
19	P-24309	Screw	52	P-18475	Spring
20	P-15230	Bumper	53	P-07382	Latch Pin
21	P-32143	E Ring	54	P-24480	Cap Screw - 2PCS
◆ 22	P-64454	O-Ring	55	P-12471	Magazine Cover
23	P-96134	Pipe	56	P-07380	Spring Pin - 3PCS
◆ 24	P-64455	O-Ring	57	P-96136	Cover Stop
25	P-01314	Body	59	P-07384	Dowel Pin
26	P-18228	Spring	60	P-24481	Set Screw
◆ 27	P-15231	Return Seal	61	P-09208	Pusher
◆ 28	P-64239	O-Ring	62	P-09223	Pusher - 2PCS
29	P-22114	Bleeder Valve	63	P-18476	Pusher Spring - 3PCS
◆ 30	P-64241	O-Ring	64	P-27188	Wear Rails - 7PCS
31	P-18227	Spring	65	P-07383	Spring Pin
32	P-22139	Plunger	66	AS-12212	Magazine Assembly
◆ 33	P-64240	O-Ring	67	P-24306	Cap Screw

◆ Parts Included In AS- 97416 O-Ring And Seal Kit