


MODEL T1S3832

SPOTNAILS®

Division of Peace Industries, LTD.

1100 Hicks Road, Rolling Meadows, IL 60008
 P: 800-873-2239 / 847-259-1620 • F: 888-369-2588
 customerservice@spotnails.com
 www.spotnails.biz • www.spotnails.com



Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24300	Cap Screw - 6PCS	31	P-64391	O-Ring
02	P-32211	Flat Washer - 4PCS	32	P-18267	Spring
03	P-70062	Exhaust Deflector	33	AS-21039	Selectable Trigger (Blue)
04	P-60229	Cap	34	P-15157	Return Seal
05	P-15193	Exhaust Seal	35	P-53165	Safety Guide
06	P-64384	O-Ring	36	P-18328	Spring
07	P-18331	Poppet Spring	37	AS-53099	Safety Assembly
08	P-64232	Poppet O-Ring	38	AS-04036	Latch Assembly
09	P-63042	Poppet	39	P-64434	O-Ring
10	P-64422	Piston Stop O-Ring	40	AS-10051	Front Plate Assembly
11	P-64467	Cylinder Seal O-Ring	41	P-07356	Step Pin
12	P-03081	Guide Spacer	42	P-07353	Spiral Pin
13	P-62098	Gasket	43	P-08481	Wear Plate
14	P-64424	Piston O-Ring	44	P-26125	Nut
15	P-06236	Driver Blade	45	P-24452	Screw
16	AS-06054	Piston & Driver Assembly	46	P-07290	Pin
17	P-05106	Cylinder	47	P-26142	Nut - 3PCS
18	P-64235	Cylinder O-Ring	48	P-32170	Washer - 3PCS
19	P-64423	O-Ring	49	P-13142	Bracket
20	P-15121	Bumper	50	P-24307	Screw
21	P-15124	Return Seal	51	AS-99086	Magazine Cover Assembly
22	P-01316	Body	52	P-18332	Spring
23	P-64240	O-Ring	53	P-05098	Fixed Spacer
24	P-07327	Trigger Pin	54	P-24310	Screw - 3PCS
25	P-07262	Pin	55	P-12352	Track
26	P-15194	Valve Seal	56	P-18233	Spring Clip
27	P-18283	Spring	57	P-18232	Negator Spring
28	P-64390	O-Ring	58	P-09158	Pusher
29	P-22232	Plunger	64	AS-53115	Safety Pin Kit
30	P-22166	Valve Housing			
◆ Parts Included In AS- 97417 O-Ring And Seal Kit					

ACCESSORIES (NOT INCLUDED)

59	AS-53100	No Mar Safety Kit	60	P-96129	No Mar Tip
61	P-32227	Washer	62	P-26165	Nut
63	AS-21040	Sequential Trigger (Red)			