


# MODEL X1S1664



Division of Peace Industries, LTD.

1100 Hicks Road, Rolling Meadows, IL 60008  
 P: 800-873-2239 / 847-259-1620 • F: 888-369-2588  
 customerservice@spotnails.com  
 www.spotnails.biz • www.spotnails.com



| Ref No. | Part No. | Description                       | Ref No. | Part No. | Description                         |
|---------|----------|-----------------------------------|---------|----------|-------------------------------------|
|         | 01       | P-24300 Cap Screw - 4PCS          |         | 38       | P-22145 Pilot Valve                 |
|         | 02       | P-32211 Flat Washer - 4PCS        | ◆       | 39       | P-64336 O-Ring                      |
|         | 03       | P-70058 Exhaust Deflector         |         | 40       | P-18227 Spring                      |
|         | 04       | P-60221 Cap                       | ◆       | 41       | P-64383 Plunger O-Ring - 2PCS       |
| ◆       | 05       | P-15187 Exhaust Seal              |         | 42       | AS-22037 Plunger w/Housing Assembly |
| ◆       | 06       | P-64378 O-Ring                    | ◆       | 43       | P-64328 O-Ring                      |
|         | 07       | P-18327 Poppet Spring             |         | 44       | P-18267 Spring                      |
| ◆       | 08       | P-64601 Poppet O-Ring             |         | 45       | AS-21031 Selectable Trigger (Blue)  |
|         | 09       | P-63055 Poppet                    |         | 46       | P-26126 Nut - 2PCS                  |
| ◆       | 10       | P-64379 Piston Stop O-Ring        |         | 47       | P-32170 Washer - 9PCS               |
| ◆       | 11       | P-64602 Cylinder Seal O-Ring      |         | 48       | P-13135 Bracket                     |
| ◆       | 12       | P-62094 Gasket                    |         | 49       | P-24307 Screw - 2PCS                |
| ◆       | 13       | P-64617 Piston O-Ring             |         | 50       | P-26159 Nut Plate - 2PCS            |
|         | 15       | AS-06110 Piston & Driver Assembly |         | 51       | P-24358 Screw - 4PCS                |
|         | 16       | P-03125 Guide Spacer              |         | 52       | P-24308 Screw                       |
|         | 17       | P-05131 Cylinder                  |         | 54       | P-32229 Washer - 7PCS               |
| ◆       | 18       | P-64603 Cylinder O-Ring           |         | 55       | P-12624 Magazine Cover              |
| ◆       | 19       | P-64604 O-Ring                    |         | 56       | P-07335 Negator Spring Pin          |
|         | 20       | P-03126 Cylinder Guide            |         | 57       | P-18334 Negator Spring              |
| ◆       | 21       | P-64605 O-Ring                    |         | 58       | P-24434 Screw - 2PCS                |
|         | 22       | P-15278 Bumper                    |         | 59       | P-10285 Stationary Front Plate      |
|         | 23       | P-15198 Return Seal               |         | 61       | P-10349 Removable Front Plate       |
| ◆       | 24       | P-64240 O-Ring - 2PCS             |         | 63       | P-08531 Wear Plate                  |
|         | 25       | P-01308 Body                      |         | 64       | P-07357 Pin                         |
|         | 26       | P-64312 O-Ring                    |         | 65       | P-18333 Latch Spring                |
|         | 27       | P-60156 End Cap                   |         | 66       | P-04119 Quick Clear Latch           |
|         | 28       | P-53165 Safety Guide              |         | 67       | P-07334 Pin                         |
|         | 29       | P-18328 Spring                    |         | 68       | P-12630 Magazine                    |
|         | 30       | AS-53111 Safety Assembly          |         | 69       | P-09186 Pusher                      |
|         | 31       | P-07327 Trigger Pin               |         | 74       | AS-22041 Plunger w/O-Rings Assembly |
|         | 32       | P-07262 Pin                       |         | 75       | P-22233 Valve Housing               |
| ◆       | 33       | P-64332 Valve Housing O-Ring      |         | 76       | AS-22043 Trigger Valve Assembly     |
|         | 34       | P-22144 Trigger Valve Cap         |         | 78       | AS-53112 Safety Pin Kit             |
| ◆       | 35       | P-64333 O-Ring                    |         | 79       | P-13158 Bracket                     |
| ◆       | 36       | P-64334 O-Ring                    |         | 80       | P-24731 Screw - 2PCS                |
| ◆       | 37       | P-64335 O-Ring                    |         | 81       | AS-12238 Magazine Cover Assembly    |

◆ Parts Included In AS- 97403 O-Ring And Seal Kit

## ACCESSORIES (NOT INCLUDED)

|    |          |                        |    |          |                          |
|----|----------|------------------------|----|----------|--------------------------|
| 70 | AS-53085 | Lathing Safety Adapter | 73 | AS-21037 | Sequential Trigger (Red) |
| 71 | P-97454  | Air Filter             | 77 | AS-99105 | Walking Stick Attachment |