CONTROLS REPLACEMENT

PARCTLCY 160A



WARNING!

Disconnect evaporative cooler from electrical source before beginning work on product. Electrical shock resulting in injury or death can occur when working in a wet environment. Perform all maintenance with evaporative cooler unplugged.

Before beginning

Position evaporative cooler with plenty of working room on all sides. Disconnect evaporative cooler from electrical and water supplies. The two back casters on the evaporative cooler must be in the locked position before beginning to work on this product.

Remove the KUUL® evaporative media

Step 1

Lock the casters to keep the evaporative cooler from moving while you are working. Remove the evaporative media flap attached to the top of the evaporative cooler with screws. Remove the screws and set the evaporative media flap aside.

Step 2

All KUUL evaporative media must be removed before accessing the inside of the evaporative cooler housing. Remove the center piece of the evaporative media first by grasping at the top and tilting it out and away from the evaporative cooler. While tilting the evaporative media out, lift the piece up and out.

Step 3

Remove remaining evaporative media in the same manner. Set aside in a safe place to prevent damage while out of the evaporative cooler. Once all the evaporative media has been removed, you should have access to the inside of the evaporative cooler housing and internal components.



STEP 1



STEP 2

Controls replacement

(KUUL evaporative media must be removed)

Step 1

Once the media has been set aside, locate the control box inside the housing and remove the four screws that hold the box in place.

Step 2

Open the control box to expose the cords. Disconnect all of the cords from the switches and remove the zip ties that are holding the cords inside the box. **DO NOT CUT ELECTRICAL WIRES.**

Step 3

The control box should then slide out easily. Discard the old control box.

Step 4

Reattach the cords to the switches and tightly close the new control box. Slide the box back into the housing and secure with the four screws.

Step 5

Replace the evaporative media, beginning on the outer edges and working towards the center. Pay close attention to the stickers on the evaporative media - the arrow sticker should point up and inward. Replace the evaporative media flap, securing it with screws.



STEP 1



STEP 3



STEP 4



