

- 1 Disconnect main power.
 - 2 Remove front cover or panel cover.
 - 3 Remove 1" knockout from box.
 - 4 Feed wires through knockout hole and install unit with supplied nut.
 - 5 Connect green wire to the (earth) ground. Trim extra wire as needed; a shorter wire is better. Ground bus resistance should be less than 5 Ohms for best performance.
 - 6 Connect white wire to neutral.
 - 7 Connect black wire to load side of circuit. Trim extra wire as needed; a shorter wire is better.
 - 8 Replace front/panel cover.
 - 9 Restore power.
- Electrical Installation: Install P/N: ED0585 | LT10643 | Rev. B




SPACE AGE
ELECTRONICS
1.800.486.1723 | www.1SAE.com

E120V-GT Surge Protection Device | Volts: 120 | 5000A Breaker Trip

Circuit lockout kit as required by NFPA 72 2013 10.6.5.2 with identification labels and key included!

Installation and wiring should be performed by qualified personnel only. Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state, and federal codes and/or standards set by the authority having jurisdiction. This package contains all necessary parts to install and mount in an electrical box. Use in conjunction with a 30A circuit breaker. The conductors used to connect the SPD to the line and ground shall be no longer than necessary and avoid unnecessary bends. When LED is illuminated, SPD is operating properly.



- 1 Disconnect main power.
 - 2 Remove front cover or panel cover.
 - 3 Remove 1" knockout from box.
 - 4 Feed wires through knockout hole and install unit with supplied nut.
 - 5 Connect green wire to the (earth) ground. Trim extra wire as needed; a shorter wire is better. Ground bus resistance should be less than 5 Ohms for best performance.
 - 6 Connect white wire to neutral.
 - 7 Connect black wire to load side of circuit. Trim extra wire as needed; a shorter wire is better.
 - 8 Replace front/panel cover.
 - 9 Restore power.
- Electrical Installation: Install P/N: ED0585 | LT10643 | Rev. B




SPACE AGE
ELECTRONICS
1.800.486.1723 | www.1SAE.com

E120V-GT Surge Protection Device | Volts: 120 | 5000A Breaker Trip

Circuit lockout kit as required by NFPA 72 2013 10.6.5.2 with identification labels and key included!

Installation and wiring should be performed by qualified personnel only. Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state, and federal codes and/or standards set by the authority having jurisdiction. This package contains all necessary parts to install and mount in an electrical box. Use in conjunction with a 30A circuit breaker. The conductors used to connect the SPD to the line and ground shall be no longer than necessary and avoid unnecessary bends. When LED is illuminated, SPD is operating properly.



- 1 Disconnect main power.
 - 2 Remove front cover or panel cover.
 - 3 Remove 1" knockout from box.
 - 4 Feed wires through knockout hole and install unit with supplied nut.
 - 5 Connect green wire to the (earth) ground. Trim extra wire as needed; a shorter wire is better. Ground bus resistance should be less than 5 Ohms for best performance.
 - 6 Connect white wire to neutral.
 - 7 Connect black wire to load side of circuit. Trim extra wire as needed; a shorter wire is better.
 - 8 Replace front/panel cover.
 - 9 Restore power.
- Electrical Installation: Install P/N: ED0585 | LT10643 | Rev. B




SPACE AGE
ELECTRONICS
1.800.486.1723 | www.1SAE.com

E120V-GT Surge Protection Device | Volts: 120 | 5000A Breaker Trip

Circuit lockout kit as required by NFPA 72 2013 10.6.5.2 with identification labels and key included!

Installation and wiring should be performed by qualified personnel only. Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state, and federal codes and/or standards set by the authority having jurisdiction. This package contains all necessary parts to install and mount in an electrical box. Use in conjunction with a 30A circuit breaker. The conductors used to connect the SPD to the line and ground shall be no longer than necessary and avoid unnecessary bends. When LED is illuminated, SPD is operating properly.



- 1 Disconnect main power.
 - 2 Remove front cover or panel cover.
 - 3 Remove 1" knockout from box.
 - 4 Feed wires through knockout hole and install unit with supplied nut.
 - 5 Connect green wire to the (earth) ground. Trim extra wire as needed; a shorter wire is better. Ground bus resistance should be less than 5 Ohms for best performance.
 - 6 Connect white wire to neutral.
 - 7 Connect black wire to load side of circuit. Trim extra wire as needed; a shorter wire is better.
 - 8 Replace front/panel cover.
 - 9 Restore power.
- Electrical Installation: Install P/N: ED0585 | LT10643 | Rev. B



SPACE AGE
ELECTRONICS
1.800.486.1723 | www.1SAE.com

E120V-GT Surge Protection Device | Volts: 120 | 5000A Breaker Trip

Circuit lockout kit as required by NFPA 72 2013 10.6.5.2 with identification labels and key included!

Installation and wiring should be performed by qualified personnel only. Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state, and federal codes and/or standards set by the authority having jurisdiction. This package contains all necessary parts to install and mount in an electrical box. Use in conjunction with a 30A circuit breaker. The conductors used to connect the SPD to the line and ground shall be no longer than necessary and avoid unnecessary bends. When LED is illuminated, SPD is operating properly.