



## Product Specifications/Installation Sheet

**Item # MS-00017/18**

**Item: Single Wall Mounted Ballet Bars**

### **Warning:**

**Read ALL instructions thoroughly before using any and all equipment manufactured or distributed by Gibson Inc. Because of the nature of the sport, the possibility of injury is inherent in gymnastic and athletic activity. The equipment is intended for use only by properly trained and qualified participants under supervised conditions. When you use Gibson products, know your limitations and the limitations of your equipment. Keep your equipment in good condition by inspecting for loose fittings or damage and test for stability before each use.**

### **Product Description:**

**Gibson Single Wall Mounted Ballet Bar Brackets are forged from high quality steel and finished in triple chrome powder coat finish. Units come complete with hardware for mounting to a wood stud. The bracket collar has an appropriate inside diameter, ideal for a 1.5" or 1.75" diameter rail.**

### **Package Includes:**

1. Rail(s) per order

**Single wall mounted ballet bars will consist of the following (per bracket):**

1. One ballet bar bracket
2. Two 3/8" x 2" lag screws
3. Two #10 x 3/4" tapping screws

### **Tools Required:**

1. Phillips Screwdriver
2. One 9/16" (14mm) Socket or Wrench
3. Drill with 7/32" bit
4. Drill with 5/32" bit





## Product Specifications/Installation Sheet

Item # MS-00017/18

Item: Single Wall Mounted Ballet Bars

### Product Installation:

1. Lay the entire rail out in the proper order so that rail sections join at the brackets. The brackets should be mounted at the wall stud. Mark the joint locations on the wall with a pencil.
2. Standard height for adult use is 42" from the floor to the top of the rail. Place bracket in correct spot on the wall, making sure that all brackets are level. Mark holes with a pencil. Drill with a 7/32" drill bit approximately 2" deep and install the bracket to the wall using the 3/8" x 2" lag screws included.
3. Position the rails in the brackets so that the joint is in the center of the bracket. Assemble the rails by screwing the dowel screw into the pre-drilled hole at the end of the other rail. Be sure to tighten the two sections of the rail as securely as possible.
4. Drill through the bracket holes with a 5/32" drill bit. Using the #10 self tapping screws provided, securely fasten the rail to the bracket.

+++++

**\*\*IMPORTANT\*\***

**BALLET BARS SHOULD BE USED FOR SUPPORT ONLY.  
DO NOT HANG ON THE BAR**

### Guarantee:

Gibson equipment is guaranteed for a period of one year from the date of invoice against faulty manufacturing or defects in material. The seller's sole obligation under this warranty shall be to repair or, at its discretion, replace at its expense any defective part or parts. Material claimed defective must be returned prepaid by customer to us for examination, if requested. Damage caused by extreme usage or misuse will not be covered.